

## OVERHEAD PANEL - SURFACE MOUNT

\*Used to mount panels on top of horizontal overhead structure for continuous plant coverage